3'-0"

3" | 6" | 6" | 6" | 6" | 6" | 3"

3/4"

Fastener #2B
$\frac{1}{4}$-14 x 1" LL
Type AB W/Washer

PBU Fastener Location At Panel Ends

3'-0"

3" | 1'-0" | 1'-0" | 9"

3/4"

Fastener #2B
$\frac{1}{4}$-14 x 1" LL
Type AB W/Washer

PBU Fastener Location
At Intermediate Supports

Prevailing Wind

Installation

Fastener #4
$\frac{1}{4}$-14 x $\frac{7}{8}$" LL SD
W/Washer At
1'-8" O.C.

Tape Sealant
$\frac{1}{2}$" x $\frac{3}{32}$" [HW-507]

PBU Panel Sidelap