



Existing Gutter

Note:
Offsets Must Be
Added To Existing
Downspouts To
Clear The NuWall
Panel

NuWall Cap Trim [T-6220]
(Use With Existing PBR
Panel Only)

Fastener #4A
1/4-14 x 7/8" SD W/ Washer
At 1'-0" O.C.

NuWall Outside Closure
[HW-424]

NuWall Panel

Existing PBR Panel

Existing Roof Panel

Existing Fasteners

Fastener #4A
1/4-14 x 7/8" SD W/ Washer
At 1'-0" O.C. Into High Ribs

2 1/2"

Eave Strut

Fastener #4A
1/4-14 x 7/8" SD W/ Washer
At 1'-0" O.C. Into Existing
Wall Panel

Fastener #4A
1/4-14 x 7/8" SD W/ Washer
At Side Lap