


PBC Fastener Location  
At Panel Ends And Endlaps

PBC Fastener Location  
At Intermediate Supports



Horizontal PBC Panel Sidelap